

PRODUCT DESCRIPTION

Danterr's Combination Slab on Ground (SOG) Bar Chairs are durable, dual-height plastic spacers designed to support reinforcing mesh or bar in ground slabs, pod slabs, and pool bases. Manufactured from selected recycled plastics, they eliminate the risk of rust and are puncture-resistant due to their polymer membranes, compliant with AS/NZS 2425:2015.

These lightweight, stackable bar chairs provide two cover heights in one unit, offering flexibility across slab thicknesses. A 200mm base plate is available separately for added stability in soft substrates like sand.



FEATURES & BENEFITS

- Dual-height functionality in one chair
- Non-corrosive plastic won't rust in wet environments
- Flat base protects plastic membranes from damage
- An optional base plate is available for sand-based or unstable subgrades
- Stackable for easy handling, storage, and transport
- Tested to meet strength requirements for slab construction

APPLICATIONS

- Commercial ground slabs
- Pod slab systems
- In-ground pool reinforcement
- Precast and tilt-up bases
- Soft sand and membrane-covered sites (with base plate)

PACKAGING & AVAILABILITY

Product Code	Description
101457	Bar Chairs Combination SOG 25/40 (100Pk)
101458	Bar Chairs Combination SOG 50/65 (100Pk)
101460	Bar Chairs Combination SOG 75/90 (100Pk)
101462	Bar Chairs Combination SOG 85/100 (100Pk)
101489	Tall Bar Chairs Combination SOG 105/110 (100Pk)
105033	Tall Bar Chairs Combination SOG 115/120 (100Pk)
107386	Tall Bar Chairs Combination SOG 125/130 (100Pk)
107387	Tall Bar Chairs Combination SOG 135/140 (100Pk)
101490	Tall Bar Chairs Combination SOG 145/150 (100Pk)

Optional Base Plates:

Product Code	Description
112528	Bar Chair Combination SOG Base 200mm

TECHNICAL SPECIFICATIONS

PHYSICAL PROPERTIES

Property	Specification
Material	Selected Recycled Plastic
Chair Type	Non-cliptop, dual-height bar chair
Cover Sizes Available	25/40mm to 145/150mm
Stability Add-On	Optional 200mm base
Stackable	Yes
Rust Proof	Yes
Membrane Friendly	Yes – flat base reduces puncture risk

Combination SOG Bar Chairs

SAFETY

- Non-toxic and safe for manual handling
- Gloves recommended for high-volume installation
- Follow site-specific manual handling protocols

INSTALLATION INSTRUCTIONS

- Place chair flat on prepared subgrade or plastic membrane
- Insert a reinforcement bar or mesh into the centre saddle
- For unstable ground, attach an optional 200mm base plate
- Space chairs according to engineering drawings and pour schedule